

User Manual

Intel LGA1156 (i3 / i5) - Igloo 1100 CU Series

Igloo 1100 CU Series (Fan with 1B1S Bearing)

Igloo 1100 CU (E) Series (Fan with Entering Bearing)

Igloo 1100 CU (2B) Series (Fan with Two-Ball Bearing)




Inspiring Cooling Technology
www.GlacialTech.com

• Installation




Step 1

Remove the plastic cover.




Step 2

Place the fasteners at the motherboard's holes.




Step 3

Make sure that all the fasteners are at the original status.




(Error!)




Step 4

Push down on the top of fasteners, you should hear a "click" when pushing down the fastener.



(Error!)

Do not put hands on the top of fan as the pressing point by installation in order to avoid fan hub damage.



Step 5

Connect the fan cable to the motherboard CPU fan header.

- FAN APPROVED BY CE & TUV & UL
- The specifications are subject to change without notice. All brand names and trademarks are the properties of their respective owners.

For further information, please consult our website: www.GlacialTech.com

© 2009 GlacialTech Inc. All rights reserved.